

POST SPACING CHART

Measure the actual distance between any two end, corner or gate posts. Find this distance on the table. The dimension indicates the interval between line posts to be used.

Space	Set Posts Apart	Space	Set Posts Apart	Space	Set Posts Apart
30ft.	10ft.	64ft.	9ft.	97ft.	9ft. 7in.
31ft.	7ft. 9in.	65ft.	9ft. 3in.	98ft.	9ft. 8in.
32ft.	8ft.	66ft.	9ft. 5in.	99ft.	9ft. 9in.
33ft.	8ft. 3in.	67ft.	9ft. 7in.	100ft.	10ft.
34ft.	8ft. 6in.	68ft.	9ft. 8in.	101ft.	9ft. 2in.
35ft.	8ft. 9in.	69ft.	9ft. 10in.	102ft.	9ft. 3in.
36ft.	9ft.	70ft.	10ft.	103ft.	9ft. 4in.
37ft.	9ft. 3in.	71ft.	8ft. 9in.	104ft.	9ft. 5in.
38ft.	9ft. 6in.	72ft.	9ft.	105ft.	9ft. 6in.
40ft.	10ft.	73ft.	9ft. 2in.	106ft.	9ft. 7in.
41ft.	8ft. 2in.	74ft.	9ft. 3in.	107ft.	9ft. 8in.
42ft.	8ft. 5in.	75ft.	9ft. 4in.	108ft.	9ft. 9in.
43ft.	8ft. 6in.	76ft.	9ft. 6in.	109ft.	9ft. 10in.
44ft.	8ft. 9in.	77ft.	9ft. 7in.	110ft.	10ft.
45ft.	9ft.	78ft.	9ft. 9in.	111ft.	9ft. 3in.
46ft.	9ft. 2in.	79ft.	9ft. 10in.	112ft.	9ft. 4in.
47ft.	9ft. 5in.	80ft.	10ft.	113ft.	9ft. 5in.
48ft.	9ft. 7in.	81ft.	9ft.	114ft.	9ft. 6in.
49ft.	9ft. 9in.	82ft.	9ft. 1in.	115ft.	9ft. 7in.
50ft.	10ft.	83ft.	9ft. 3in.	116ft.	9ft. 8in.
51ft.	8ft. 6in.	84ft.	9ft. 4in.	117ft.	9ft. 9in.
52ft.	8ft. 8in.	85ft.	9ft. 6in.	118ft.	9ft. 10in.
53ft.	8ft. 10in.	86ft.	9ft. 7in.	119ft.	9ft. 10in.
54ft.	9ft.	87ft.	9ft. 8in.	120ft.	10ft.
55ft.	8ft. 2in.	88ft.	9ft. 9in.	121ft.	9ft. 3in.
56ft.	9ft. 4in.	89ft.	9ft. 10in.	122ft.	9ft. 4in.
57ft.	9ft. 6in.	90ft.	10ft.	123ft.	9ft. 5in.
58ft.	9ft. 8in.	91ft.	9ft. 2in.	124ft.	9ft. 6in.
59ft.	9ft. 10in.	92ft.	9ft. 2in.	125ft.	9ft. 7in.
60ft.	10ft.	93ft.	9ft. 3in.	126ft.	9ft. 8in.
61ft.	8ft. 8in.	94ft.	9ft. 5in.	127ft.	9ft. 9in.
62ft.	8ft. 1in.	95ft.	9ft. 6in.	128ft.	9ft. 10in.
63ft.	9ft.	96ft.	9ft. 7in.	129ft.	9ft. 10in.



800-882-5543